

Storage Instructions

All Micronet products must be stored based on these instructions:

1. Temperature - 5 to 40 degrees Celsius.
2. Humidity -10%-60% (non-Condensing).
3. Charging - charging cycle every six months (for product with battery).
4. Micronet OS/SW – update to latest every quarter (when available).